

Tone List

PIANO		BRASS	
00	GRAND PIANO	50	TRUMPET
01	BRIGHT PIANO	51	TROMBONE
02	STRINGS PIANO	52	TUBA
03	ELEC.GRAND PIANO	53	MUTE TRUMPET
04	ELEC.PIANO 1	54	FRENCH HORN
05	ELEC.PIANO 2	55	BRASS
06	HARPSICHORD	56	SYNTH-BRASS 1
07	CLAVI	57	SYNTH-BRASS 2
08	THUMB PIANO	WOOD WIND	
MELODIC PERC.		58	ALTO SAX
09	VIBRAPHONE	59	TENOR SAX
10	MARIMBA	60	SOPRANO SAX
11	XYLOPHONE	61	BARITONE SAX
12	CELESTA	62	OBOE
13	GLOCKENSPIEL	63	ENGLISH HORN
14	TUBULAR BELL	64	BASSOON
15	STEEL DRUMS	65	CLARINET
ORGAN		66	FLUTE
16	ELEC.ORGAN	67	PICCOLO
17	PERC.ORGAN	68	RECORDER
18	ROCK ORGAN	69	PAN FLUTE
19	PIPE ORGAN	70	WHISTLE
20	REED ORGAN	71	OCARINA
21	ACCORDION	SYNTH/PAD	
22	HARMONICA	72	SQUARE LEAD

Rhythm List

POPS	
00	STRAIGHT 8 BEAT
01	8 BEAT POP
02	MELLOW 8 BEAT
03	60's 8 BEAT
04	16 BEAT 1
05	16 BEAT 2
06	16 BEAT SHUFFLE
BALLAD	
07	POP BALLAD
08	MODERN BALLAD
09	16 BEAT BALLAD
10	6/8 BALLAD
DANCE	
11	EDM
12	TECHNO POP
13	TRANCE
14	MODERN DANCE
15	DISCO SOUL
ROCK/JAZZ	
16	STRAIGHT ROCK
17	BLUES
18	SLOW ROCK
19	MIDDLE BIG BAND
20	JAZZ WALTZ
EUROPEAN	

Drum Map

Key	99:DRUM SET
F2	Synth Kick
F#2	Synth Snare 1
G2	Synth Snare 2
G#2	Dance Kick 2
A2	Dance Kick 1
Bb2	Dance Snare 1
B2	Dance Snare 2
C3	Dance Clap
C#3	Snare 3
D3	Brush Snare Slap
Eb3	Brush Snare Sweep
E3	Kick 2
F3	Kick 1
F#3	Side Stick
G3	Snare 1
G#3	Closed Hi-Hat
A3	Snare 2
Bb3	Open Hi-Hat
B3	Low Tom
C4	Mid Tom
C#4	Crash Cymbal
D4	High Tom
Eb4	Ride Cymbal
E4	Xiao Luo
F4	Vibraslap